

COOKTOP PARTS
Whirlpool For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0
(Black) (Designer White) (Designer Biscuit) (Stainless Steel)




	art No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
975 975 W101 976	57143 110369 62973	Literature Parts Installation Instructions Anti–Tip Template English/Spanish English/French Owners Manual Tech Sheet Safer Cooking Tips	3	3191901 3191903 8273344 3191898 3191899 8273343 4455981 4455980	Grey Espresso R. Front, L. Rear Black Grey Espresso Right Rear Black Grey Espresso Burner Left Front R. Front, L. Rear Right Rear Cooktop White Biscuit	5 6 7 8	8522623 8522626 8273281 8522624 8522627 8522851 8522850	White Biscuit Knob, Control (3) Stainless Steel White Biscuit Knob, Powerburner Black White Biscuit Grate, Burner (4) Black Grey Espresso Screw

CONTROL PANEL PARTS
For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0
(Black) (Designer White) (Designer Biscuit) (Stainless Steel)



Illus	. Part		Illus	. Part		Illus	. Part	<b>*</b>
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1		Endcap, Left Hand	3		Panel, Control	11	3196169	Screw
	W10009080			W10005840	•	12		Control, Range
	W10009040	White		W10005820	White		W10114384	
	W10009060	Biscuit		W10005830	Biscuit		W10114383	White
		Endcap, Right Hand		W10117565	Silver for Stnlss		W10114385	Biscuit
	W10009090	Black	5	9758080	Module, Spark	13	3196178	Screw
	W10009050	White	6		Brkt-Mntg, Console	14	9757609	
	W10009070	Biscuit	7	8523412	Bracket, Support	15		Brkt, Mntg EOC
2	8053505	Shield, Lower Heat	8		Cover, Upper	16	9762726	Brkt-Mntg, DSI
			9		Shield, Heat	17	8273564	Clip
			l 10	8273132	Cover. Lower			

MANIFOLD PARTS
For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0
(Black) (Designer White) (Designer Biscuit) (Stainless Steel)




MANIFOLD PARTS
For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0
(Black) (Designer White) (Designer Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve
2		Burner Base
	8273700	Large (3)
	8273701	Small (1)
3		Tubing, Burner
	0070000	W/Orifice
	8273693	Left Front
	8273698 8273695	Left Rear Right Front
	8273697	Right Rear
4	8523402	Tubing (Manifold
-		to Regulator)
5	8523406	Harness, Igniter
		(W/Switches)
6	8523793	Electrode (4)
7	9762230	Pipe, Manifold
8	9757218	Valve LF – RF – LR
	8273004	Right Rear
9	8273060	Nut (4)
10	8273062	Screw (4)
11	3400228	Bolt
12	8054078	Burner, Broiler
13	8053970	Spreader, Flame
4.4	0750070	(Oven)
14 15	9758078 9761959	Burner, Bake Valve/Regulator
16	9701939	Igniter
10	8054129	Broil
	9758079	Bake
17	8272222	Tubing (Broiler
		Fitting To Valve)
18	3186489	Fitting, Broiler
19	8272403	Cover, Igniter
20	8273064	Orifice, Burner Left Front
	8273065	Right Front
	8273066	Left Rear
	8273067	Right Rear
21	8053262	Spreader, Flame
		(Broiler)
23	3196265	Screw
24	3196176	Screw
25 26	3196385 3400016	Screw
20	3400010	Screw

Following Parts Not Illustrated

8523418 Spuds, LP Gas (Kit of 4)


CHASSIS PARTS
For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0
(Black) (Designer White) (Designer Biscuit) (Stainless Steel)



CHASSIS PARTS
For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0
(Black) (Designer White) (Designer Biscuit) (Stainless Steel)

Illus No.		DESCRIPTION	Illus No.		DESCRIPTION	Illus No.		DESCRIPTION
-110.	110.	DECCINI HON			BEGGINI HON		110.	DECCINI HON
1	W10012240		19	9758701	Spacer, Door	37	3196178	Screw
2	8272747	Shield, Flue	20	9757098	Back, Main	38	3196152	Screw
3	8273036	Burner Box	21	8522416	Seal, Oven	39		Screw
4		Panel, Side (2)	22	8053971	Brace, Main Back		3196166	White
	8053830	White-Textured	23		Retainer, Insul.		8281194	Biscuit
	8272519	Biscuit-Textured		9761449	Left Hand	41	W10031780	Screw
	8053832	Black-Textured			Right Hand	42	3196179	Screw
6	8523249	Brkt, Manifold Mtg	24		Clip, Panel (6)	44	3196177	Screw
8		Frame, Front	25	9757891	Cord, Power	45	3196168	Screw
		(Not Serviced)	26	9760407	Brkt – Hinge	46	9757239	Rod – Door Switch,
9	3196037	Foot, Front (2)	27	9757262	SWITCH, DOOR			Rear Mount
10	W10058460	Foot, Rear (2)	28	3196701	Light Socket Assy	47	3196560	Screw
11	3195097	Bottom, Oven	29	311255	Bulb, Oven Light			
12	8273902	Sensor, Oven	30	9761013	Latch, Door	INS	ULATION	
13	8053967	Baffle, Burner	31	W10078370	Rod, Latch			
14	8053969		32	W10107820	Latch-Mtr			Insulation, Wrap
15	8053968	Shield, Lower	33	9759785	Glide, Drawer			Insulation, Back
16	9760314	Rail, Base (2)	35		Insulation		8272613	Insulation, Vent
18	W10008830	Seal, Oven Flange	36	9761512	Clip, Mounting			

DOOR PARTS
For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0
(Black) (Designer White) (Designer Biscuit) (Stainless Steel)




# **DOOR PARTS**

For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0 (Black) (Designer White) (Designer Biscuit) (Stainless Steel)

Illus No.		DESCRIPTION
1		Trim, Top
	9762391	Black
	9761975	
	9761976	
		Stainless Steel
2	3196164	
2	0.00.0.	Handle, Door
_	9761983	Black
	9761982	
	9761984	
4	9761344	
5	W10031790	
6	9758162	
7	3186289	Frame, Glass
8	8272618	Insulation, Door
9	9761357	Retainer, Insul.
10	9761493	Hinge, Door
11		Glass, Outer Door
	W10075990	Black
	W10075980	White
	W10076000	Biscuit
	9756435	Stainless Model
12		Trim, Door Side
		Left Hand
	8523171	Black
	8523172	White
	8523173	Biscuit
		Right Hand
	8523165	Black
	8523166	White
	8523167	Biscuit
13	3196160	
14	3196165	Screw
15	3196025	Clip, Door Glass
16	W10113759	Strap, Door
17	3196794	Bracket, Window(2)
18	0-004	Trim, Bottom
	8523177	
	8523175	
	8523178	
4.0	8523180	
19	9761517	Clip, Door Mntg
20	W10031780	Screw

## **DRAWER & BROILER PARTS**

For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0 (Black) (Designer White) (Designer Biscuit) (Stainless Steel)



# **OPTIONAL PARTS (NOT INCLUDED)**

For Models: SF265LXTB0, SF265LXTQ0, SF265LXTT0, SF265LXTS0 (Black) (Designer White) (Designer Biscuit) (Stainless Steel)

Parts Not Illustrated and Optional Parts (Not Included)

### SPLICING WIRES--25FT. LENGTH

Part

Illus.

242828 Wire, Black 12 Ga. 150° c 242821 Wire, Blue 14 Ga. 150°c 242822 Wire, Brown 14 Ga. 150°c 242830 Wire, Brown 14 Ga. 200°c 242823 Wire, Green 14 Ga. 150°c 242824 Wire, Orange 14 Ga. 150°c 242825 Wire, Red 14 Ga. 150°c 242831 Wire, Red 14 Ga. 200°c

### **REFINISHING MATERIAL**

242756 Touch-Up Self-Clean(1/2 Pt) 261582 Grease Illus. Part
No. No. DESCRIPTION

### INSULATION

261514 Insulation, Fiberglass (1–1/2" x 24" x 120") 240132 Insulation, Fiberglass (2–1/2" x 22" x 120")

### PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit 511873 White Porcelain (2 Oz.)

# PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White 4392901 Biscuit 285006 Superior Black 206922 Primer (White)

### PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut) Illus. Part
No. No. DESCRIPTION

### **ACCESSORY PARTS**

241430 Foil, Aluminum Oven (18" x 25') 4396923 Pan – Broiler

### **ANTI-TIP KIT**

W10017440 Anti-Tip Kit

### **WIRING HARNESS PARTS**

9762433 Harness, Main
(EOC Pyro)

8524207 Harness, Wire
Bake/Broil

8523599 Harness, Wire
(Cooktop Spark)

W10045060 Harness, Wire
(DSI Ground)

3196896 Clip, Wire
3195927 Wire, Tie
313438 Clip, Harness
3196173 Screw
3196696 Clip, Harness
3196174 Screw—Grnd Harns